

USING

USING



Grandstream GXP1625 VoIP Phone QuickStart Guide


Document Release 3.2
July, 2017

PLACE A CALL ON HOLD


While on a call, press the **HOLD** key.



TAKE A CALL OFF HOLD

To resume the call, press the **HOLD** key again  or press the flashing **LINE** key.

CALL TRANSFER to PHONE




While on a call, press the **TRANSFER** key,  then:

Dial the extension number, or external 10-digit telephone number where you wish to transfer the call:

- press the transfer key again to immediately transfer the call passing the external caller ID, or
- press Send or # prior to the transfer button, the call is still attended (showing your CLID), even though you did not wait on the remote party to answer.

NOTE: You may also transfer to external telephone numbers (e.g. another office, mobile phone, etc.).

CALL TRANSFER to VOICEMAIL


While on a call, press the **TRANSFER** key,  then dial * plus the extension number (e.g. *1000), press **SEND**  (or press the # key), then press **TRANSFER** again  to complete the transfer.

VOICEMAIL

Your **MESSAGE WAITING** indicator on the top right corner of your phone is flashing red when you have a new voicemail message.

You may also receive a copy of your voicemail message in a pre-configured email Inbox. Consult your System Administrator to determine your Voicemail pre-configured User Preferences/Settings.

RETRIEVE VOICEMAIL from YOUR PHONE

- Press the **Message** key 
- Dial your Password _____
- Follow the Voice Prompts

RETRIEVE VOICEMAIL from ANOTHER PHONE:

From another **INTERNAL** Phone:

- Dial ***98**,
- Dial your mailbox number (ext. no.)
- Dial your Password


From an **EXTERNAL** Phone:

Place a call to one of your ComNet Lines:


- If Answered Live, ask to be transferred to your Voicemail, During your own Voicemail Greeting, Dial * then your Password
- If Answered by a greeting (Automated Attendant or a voicemail greeting), Dial *98 then your mailbox number,

SETUP

Your Phone has been pre-configured to seamlessly operate with the Affiliated ComNet Clear Cloud UNISON network after proper network connection has been made and power has been applied.



USING



LINE keys are used for Incoming and Outgoing call Status and Control.

USING

END A CALL

While on a call:

- Press **SPEAKER** key, or
- Replace Handset, or
- Press the **END CALL** soft key, or
- Press **HEADSET**(if using Headset)

ANSWER A CALL RINGING to YOUR PHONE

To answer a call ringing at your phone:

- Press **SPEAKER** key, or
- Lift Handset, or
- Press **HEADSET**(if using Headset)


ANSWER A CALL RINGING to ANOTHER PHONE

To answer a call ringing at another telephone:

- Press **SPEAKER** key, or
- Lift Handset, or
- Press **HEADSET**(if using Headset)

Dial ** then the **Extension Number** of the ringing telephone.

PLACE A CALL

Dial the Extension or Outside Telephone Number, then press the **#** or  (**Send**)

- Continue talking Handsfree, or
- Lift Handset, or
- Press **HEADSET**(if using Headset)

To toggle between Handset mode and Handsfree mode, press the **SPEAKER/Handsfree** key.


There is no need to dial a '1' in front of any telephone number when placing calls throughout the United States or Canada.

VOLUME ADJUSTMENT

While on a call, press the Volume Up (+) or Down (-) key. The Volume Adjustment effects the active device (e.g. Ringer when idle, handset when using handset, speaker when using speaker, etc.).

Once connected, please take a few moments to complete the following Setup practices in order to simplify, unify, and enhance everyone's experience:

FROM YOUR DESKPHONE:

- 1) Note Extension number _____
- 2) Press the **Message** key 
- 3) Dial your Password _____#
- 4) Listen to voice prompts, press option '0' for mailbox setup:
 - a) Record your **Unavailable** Voicemail Greeting
 - b) Record your **Busy** Voicemail Greeting
 - c) Record/change other mailbox options as desired.